


## **RASPBERRY PICO W**

#### MICRO CONTROLLER TRAINER

#### **MODEL-RASPBERRY-PICO-W100**

#### **SPECIFICATIONS**



This trainer has been designed with a view to provide practical and experimental knowledge of Internet of Things (IOT) with Sensors programing with Raspberry PICO W Microcontroller Board.

## **SPECIFICATIONS**

#### **A. Main Specs**

- 1. Following Parts and Modules are assembled on Single PCB of size 18 Inch x 15 Inch.
- 2. The complete circuit diagram is screen printed on component side of the PCB with circuit and Parts at the same place.
- 3. The PCB with components on front side is fitted in elegant wooden box having lock and key arrangement.
- 4. Modules and Parts should be removable without desodlering for easy repair / replacement
- 5. The acrylic cover is fitted on PCB to safeguard main parts.

## **B. Raspberry PICO W Microcontroller Board**

- 1. CPU Processor : RP2040 microcontroller chip. Dual Core Cortex M0+ at up to 133MHz
- 2. On-chip PLL allows variable core frequency
- 3. SRAM : 264 KB
- 4. Flash Memory : 2 MB
- 5. Wireless : 2.4GHz 802.11n and Bluetooth 5.2
- 6. USB : Micro USB B port for Power and Data
- 7. GPIO : 40 Pin, 26 multi-function 3.3V
- 8. Digital Inputs : 23

#### C. Sensors:

- 1. Air Humidity and Temperature DHT11
- 2. Air Quality MQ135
- 3. Soil / Water Temperature Sensor DS18B20
- 4. Leaf Wetness Sensor Rain Detector Sensor
- 5. Soil Moisture Sensor
- 6. Ambient Light Sensor LDR Light Sensor

## **D. Modules and Hardware:**

- 1. 20 X 4 LCD Display
- 2. 1 Channel Relay board
- 3. DC Motor with Motor Driver board
- 4. Stepper Motor with Motor Driver board
- 5. 7 Segment Display
- 6. Different Resistors
- 7. Red, Green, Yellow LED
- 8. 10K Pot
- 9. Push Switch 2 Nos
- 10. Audio Buzzer Board
- 11. Breadboard 400 Points
- 12. 2 mm interconnection Sockets

## **E. Accessories**

| 1. | USB to Square USB Cable                  | : 1 No                  |
|----|--|-------------------------|
| 2. | 2 mm Banana Jack Jumper – Connectors     | : 30 Nos                |
| 3. | 9V, 1A Power Adaptor – Barrel 2.1mm      | : 1 No                  |
| 4. | Pen Drive - 16 GB with All Codes         | : 1 No                  |
| 5. | Printed Manual                           | : 1 No.                 |
| 6. | Softcopy of Manual – On Pen Drive        | : 1 No                  |
| 7. | E-Books for IOT Subject – On Pen Drive   | : 10 Nos. in PDF Format |
| 8. | Mp4 Video for IOT Subject – On Pen Drive | : 40 Nos                |

## **EXPERIMENTS**

- 1. To understand theory and working of Raspberry Pico W
- 2. To understand Operating System for Raspberry Pico W
- 3. To understand Communication Protocols UART, I2C, SPI, RS232 and RS485.
- 4. To understand USB Interface for Raspberry Pico W
- 5. To understand Ethernet Cable Interface for Raspberry Pico W
- 6. To understand micro SD Card Interface for Raspberry Pico W
- 7. To understand that how to connect 20 x 4 LCD Display to Raspberry Pico W
- 8. To understand theory of Air Humidity and Temperature DHT11
- 9. To understand theory of Air Quality MQ135
- 10. To understand theory of Soil / Water Temperature Sensor
- 11. To understand theory of Leaf Wetness Sensor Rain Detector Sensor
- 12. To understand theory of Soil Moisture Sensor
- 13. To understand theory of Air Ambient Light Sensor LDR
- 14. To understand Active Audio Buzzer
- 15. To understand 1 Channel Relay Board
- 16. To understand fundamental of DC motor and its driver
- 17. To understand fundamental of Stepper Motor and its driver
- 18. To make LED blink
- 19. To connect LCD Display
- 20. To measure Humidity using Humidity DHT11 Sensor
- 21. To measure Air Humidity and Temperature using DHT11 Sensor
- 22. To measure Air Quality using Air Quality Sensor
- 23. To measure Temperature of Soil using Soil Temperature Sensor DS18B20
- 24. To measure wetness of Leaf using Leaf Wetness Sensor Rain Detector Sensor
- 25. To measure Moisture of soil using Soil Moisture Sensor
- 26. To measure Ambient Light using LDR Light Sensor
- 27. To use Audio buzzer for Output signal Alarm
- 28. To control 1 Channel Relay
- 29. To operate DC Motor control

## 30. To operate Stepper Motor

- 31. To send Sensors data to Website Cloud page using Wifi and Internet
- 32. To send Sensors data to MySQL Cloud Server and store them
- 33. To send Sensors data to Local Host Server and Store them on website html page
- 34. To send Sensors data to Mobile using GSM Gateway by SMS
- 35. To send Sensors data to Mobile using Android Mobile App
- 36. To send and display Sensors Data on website Smart Dashboard on a server

## **Contact us**

# **Registered Office**

SIGMA TRAINERS AND KITS E-113, Jai Ambe Nagar, Near Udgam School, Drive-in Road, Thaltej, AHMEDABAD-380054. INDIA.

#### Contact Person

#### Prof. D R Luhar – Director

Mobile: 9824001168Whatsapp: 9824001168

#### Phones:

| Office  | : +91-79-26852427 |
|---------|-------------------|
| Factory | : +91-79-26767512 |
|         | +91-79-26767648   |
|         | +91-79-26767649   |

# Factory

SIGMA TRAINERS AND KITS B-6, Hindola Complex, Below Nishan Medical Store, Lad Society Road, Near Vastrapur Lake, AHMEDABAD-380015. INDIA.

## E-Mails :

sales@sigmatrainers.com drluhar@gmail.com